GREEN POWER ASSEMBLY

Safety reminder: make sure to unplug from the outlet before assembling.

1. Join the **Twin Gear Housing** to the body with the Latching Arm Knobs loosened and the Latching Arms open.



Insert the Feeding Chute into the Twin Gear Housing **"neck"**, with the small rectangular tab toward the rear of the machine.

Note : *To keep machine clean and sanitary. Place the feeding chute lid when you put your machine away after cleaning. Place the Feeding Chute Lid on the top of the Feeding Chute with the two* ***"ears"*** *pointing to the sides of the juicer and the oval end toward the front of the machine-quietly push it down into position.Open the lid when you use the machine.*



2. Very important!
Assemble the **Twin Gears** as follows:
Find the **'Locating Dots'** marked on the end surface of each gear. Position the **'Locating Dots'** so that the single dot is between the other two dots.



Holding the gears in this position, insert them into the **Twin Gear Housing.** To properly engage the gears with the Drive Shaft, grasp the end of the left-hand gear ; gently twist while push it into position. Failure to **'seat'** the Twin Gears could result in damage to the Gears and the Drive Shaft which may not be covered under the warranty.

3. Put the desired **Screen** or blank into the **Twin Gear Housing.**



4. Join the **Pulp Discharge Casing** to the **Twin Gear Housing.**



5. Place each **Latching Arm** into the corresponding groove of the **Twin Gear Housing.** Turn both **Latching Arm Knobs** clockwise and tighten them until they are snug.

6. Assemble the **Outlet Adjusting Knob.**

7. Place the **Safety Tray** on the **Feeding Chute.**

FEATURES AND PARTS



Green Power Parts:

Homogenizing Blank (Open Blank) GP030 9.00	Fine Screen GP028 22.00	Coarse Screen GP029 22.00	Juice Pitcher GP025G 12.00	Cleaning Brush GP038A 5.00	Plastic Lunger GP037P3 6.00	Strainer GP010 10.00	Wooden Plunger GP036W1 6.00
Rice Cake Blank GP034 9.00	Rice Cake Guide GP035 9.00	Pasta Screen GP033-2 15.00	Pasta Attachment GP042 15.00	Pasta Screw GP031 9.00	Pasta Guide GP032 9.00	Safety Tray GP020 5.00	Feeding Chute Cover(Lid) GP006 5.00


Screen
Outlet Adjusting Knob
Pulp Dischrge Outlet
Juice Outlet
Pulp Dischrge Casing